



Assembly Instructions: Three A4 sheets (PAGE01 to PAGE03)

*Read the Assembly Instructions carefully in page order referring to the page numbers on the parts list.








- Trace along the folds with a ruler and a used pen (no ink) to get a sharper, easier fold.
- •Use a thin, even layer of glue to ensure the paper doesn't get crinkled or lumpy.

How to play

Turn the handle, and watch as the frogs bob their heads up and down in turn!







Tools and Materials



Scissors, set square, glue (such as woodwork glue). metal rod, spatula, a used pen, toothpicks, tweezers (useful for handling small parts).

Assembly tip




Before gluing, crease the paper along mountain fold and valley fold lines and make sure rounded sections are nice and stiff.


Caution





Glue, scissors and other tools may be dangerous to young children so be sure to keep them out of the reach of young children.


CREATIVE PARK Frog Chorus : Assembly Instructions


















Canon


CREATIVE PARK Frog Chorus : Assembly Instructions

















Canon